



Division of Drinking and Ground Waters

APPLIED WASTEWATER MATH FORMULA SHEET AND CONVERSION FACTORS

Table of conversion factors: 12 in = 1 ft, 27 cu. Ft. = 1 cu. Yd, 1000 mg = 1 gm, 60 sec = 1 min, 3 ft = 1 yd, 7.48 gal = 1 cu. Ft., 1000 gm = 1 kg, 60 min = 1 hour, 5280 ft = 1 mi, 8.34 lbs = 1 gal water, 1000 ml = 1 liter, 1440 min = 1 day, 144 sq. in. = 1ft^2, 62.4 lbs = 1 ft^3 water, 2.31 ft water = 1 psi, 10,000 mg/L = 1%, 43,560 ft^2 = 1 acre, 746 watts = 1hp, 0.433 psi = 1 ft water, 454 gm = 1 lb

L = Length B = Base pi = 3.14 W = Width H = Height R = Radius
Q = Flow Rate A = Area V = Volume v = velocity SG = Specific Gravity

Chlorine Demand (mg/L) = dosage (mg/L) - residual (mg/L)

AREA

Rectangle: A = L x W Triangle: A = 1/2 B x H Circle: Area = piR^2

VOLUME

Cylinder: V = piR^2H Rectangular Basin: V = L x W x H Cone: V = 1/3piR^2H

VELOCITIES and FLOW RATES

1. Velocity = distance / time

2. Q = v x A

DETENTION TIME

Detention Time = V / Q

PARTS PER MILLION / POUNDS

lbs = 8.34 lbs / gal x mg/L x MG x SG


SEDIMENTATION AND LOADINGS

1. Weir overflow rate = total flow / length of weir

2. Surface overflow rate = Influent flow / surface area

3. Solids Loading rate = solids applied / surface area

4. Efficiency, % = ((in) - (out)) / (in) x 100%



SEDIMENTATION AND LOADINGS (continued)

5. Organic loading rate (activated sludge) = $\frac{\text{CBOD applied}}{V}$

6. Hydraulic loading rate = $\frac{Q}{A}$

7. Centrifuge hydraulic loading:

$$\text{hydraulic loading rate} = \frac{Q \times \text{run time}}{\text{run time} + \text{skim time}}$$

ACTIVATED SLUDGE

1. $\text{SVI} = \frac{30 \text{ min settling, ml/L}}{\text{MLSS, mg/L}} \times 1,000$

2. $\text{SDI} = \frac{100}{\text{SVI}}$

3. Solids inventory, lbs = (Tank volume, MG) x (solids concentration, mg/L) x (8.34 lbs / gal)

4. Sludge age, days = $\frac{\text{solids under aeration, lbs.}}{\text{solids added, lbs / day}}$

5. $\text{F/M} = \frac{\text{CBOD applied}}{\text{Organic solids under aeration}}$

6. $\text{MCRT} = \frac{\text{solids inventory}}{[\text{effluent solids} + \text{WAS solids}]}$

7. Change, WAS rate, MGD = $\frac{(\text{current solids inventory, lbs}) - (\text{desired solids inventory, lbs})}{\text{WAS, mg/L} \times 8.34 \text{ lbs / gal}}$

8. Return sludge rate, MGD = $\frac{(\text{settleable solids, mL}) \times Q}{(1,000\text{mL}) - (\text{settleable solids, mL})}$

SLUDGE DIGESTION

1. Dry solids, lbs = $\frac{(\text{sludge, gal}) \times (\text{sludge, \%solids}) \times (8.34 \text{ lbs / gal}) \times \text{SG}}{100 \%}$

2. Seed Sludge, lbs volatile solids = $\frac{\text{volatile solids pumped (lbs volatile solids/ day)}}{\text{loading factor (lbs VS / day) / lb VS in digester}}$

3. Seed Sludge, gal = $\frac{\text{seed sludge (lbs volatile solids)}}{\text{seed sludge (lbs / gal)} \times \frac{(\text{solids \%})}{100\%} \times \frac{(\text{volatile solids \%})}{(100\%)}}$

4. Digested sludge removed = Total sludge in – volatile solids destroyed

5. Lime req'd, lbs = (sludge, MG) x (volatile acids, mg/L) x (8.34 lbs / gal)

6. Percent volatile solids reduction = $\frac{(\text{in} - \text{out}) \times 100\%}{\text{in} - (\text{in} \times \text{out})}$

7. VS destroyed, lbs/day/cu.ft. = $\frac{\text{volatile solids added (lbs / day)} \times \text{volatile solids reduction (\%)}}{\text{digester volume (ft}^3\text{)} \times 100\%}$

8. Gas production (cu.ft./lb VS) = $\frac{\text{gas produced (ft}^3\text{/day)}}{\text{VS destroyed (lbs/day)}}$

HORSEPOWER, FORCE, CHEMICAL PUMPS

1. Water HP = $\frac{Q(\text{gpm}) \times 8.34 \text{ lbs/gal} \times \text{head (ft)}}{33,000 \text{ ft-lbs/min}}$
2. Brake HP = $\frac{\text{Water HP}}{\text{pump efficiency}}$
3. Motor HP = $\frac{\text{BHP}}{\text{motor efficiency}}$
4. Upward force = $62.4 \text{ (lbs / ft}^3\text{)} \times \text{height (ft)} \times \text{area (ft}^2\text{)}$
5. Side wall force = $31.2 \text{ (lbs / ft}^3\text{)} \times \text{volume (ft}^3\text{)}$
6. Chemical solution, lbs / gal = $\frac{(\text{sol'n \%}) \times (8.34 \text{ lbs / gal})}{100\%}$
7. Feed pump flow, gal/day = $\frac{\text{chemical feed (lbs / day)}}{\text{chemical solution (lbs / gal)}}$
8. Scale setting, % = $\frac{\text{desired flow (gal / day)} (100\%)}{\text{maximum feed rate (gal/day)}}$
9. Total Dynamic Head = Static Head + Friction Losses
10. Static Head = Suction Lift + Discharge Head
11. $\frac{\text{polymer solution \%}}{100\%} = \frac{\text{dry polymer (lb.)}}{\text{vol. of solution (gal)} \times 8.34 \text{ (lbs/gal)}}$

LAB PROCEDURES AND MEASUREMENTS

1. TSS, mg/L = $\frac{(\text{RDD} - \text{DD})}{\text{sample vol (mL)}} \times 1\text{M}$
2. VSS, mg/L = $\frac{(\text{RDD} - \text{FDD})}{\text{sample vol (mL)}} \times 1\text{M}$

where: RDD = dried residue + dish + disc (filter) (grams)
DD = dish + disc, grams
FDD = fired residue + dish + disc, (grams)
1M = 1,000,000
3. VSS, % = $\frac{\text{volatile solids (mg/L)}}{\text{total suspended solids (mg/L)}} \times 100\%$
4. CBOD sample size (mL) = $\frac{1,200}{\text{estimated CBOD (mg/L)}}$
5. Seed correction, mg/L for 1 mL seed = $\frac{\text{seed initial D.O.} - \text{seed final D.O.}}{\text{mL seed added}}$
6. CBOD, mg/L = $\frac{[(\text{Initial DO} - \text{Final DO}) - \text{seed correction factor}] \times \text{bottle volume (mL)}}{\text{sample volume (mL)}}$
7. Initial DO = $\frac{(\text{mL sample} \times \text{DO sample}) + (\text{mL dilution water} \times \text{DO dilution water})}{\text{bottle volume (mL)}}$
8. Temperature Conversion:

$$\text{Temperature, F} = (\text{temperature C})(1.8) + 32$$