

**2007 CHEMICAL MONITORING DISTRIBUTION POINT SCHEDULE**

PWS ID: OH4700511 PWS Name: GRAFTON VILLAGE PWS  
 PWS Type: Community Purchased Surface Water Population Served: 2200  
 DISTRIBUTION ID: DS1 **Sample Monitoring Point: DS000**

Effective Date: 1/1/07

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Date
TOTAL CHLORINE (1000)	Sample in the distribution system *	
TOTAL HALOACETIC ACIDS (HAA5) (2456) TOTAL TRIHALOMETHANES (TTHM) (2950)	1 Sample(s) between 7/1/2007 to 9/30/2007	
COPPER (1022) LEAD (1030)	Not Required	

**Disinfectants and Disinfection Byproducts Sampling Information**

TTHM and HAA5 sample(s) should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect TTHM and HAA5 samples from other locations in your distribution system, use RD000 as the sample monitoring point. Any questions concerning this schedule or the Disinfectants and Disinfection Byproducts Rule can be directed to Sarah Byerly of the Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

Multiple wells drawing water from a single aquifer may be considered one treatment plant for determining the number of TTHM and HAA5 samples required, with approval from Ohio EPA.

\* Total chlorine samples are collected in the distribution system at the same time and place as total coliforms are sampled.

\*\* One sample for Chlorite at each of the following locations: near the first customer, at a location representative of the average residence time, and at a location reflecting maximum residence time of the water in the distribution system.

**Asbestos Sampling Information**

Collect one sample at a tap served by asbestos-cement pipe. The sample monitoring point (smp) code is DS000. Due to limited Laboratory capacity and a 48 hour filtering requirement, contact your lab early in the monitoring period to schedule a sampling date.

### 2007 CHEMICAL MONITORING ENTRY POINT SCHEDULE

PWS ID: OH4700411    PWS NAME: ELYRIA WATER DEPARTMENT  
PWS TYPE: Community    SOURCE: Surface Water    Sample Monitoring Point: EP001  
STU ID: 4755817    STU NAME: ELYRIA WATER DEPARTMENT  
Effective Date: 01/01/07

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Chemical Name (Code)	Monitoring Requirements	Sample Date
Consumer Confidence Report (CCR)		CCR is due July 1, 2007	
INORGANICS	ANTIMONY (1074) ARSENIC (1005) BARIUM (1010) BERYLLIUM (1075) CADMIUM (1015) CHROMIUM (1020) CYANIDE (1024) FLUORIDE (1025) MERCURY (1035) NICKEL (1036) SELENIUM (1045) THALLIUM (1085)	1 Sample(s) between 6/1/2007 to 10/31/2007	
NITRATE	NITRATE (AS N) (1040)	1 Sample(s) Monthly	
NITRITE	NITRITE (AS N) (1041)	Not Required	
RADIOLOGICALS	GROSS ALPHA (4002) RADIUM 228 (4010)	Not Required	
TOTAL ORGANIC CARBON (TOC)	TOC (2920)	1 Paired Sample Set Monthly *	
VOLATILE ORGANIC CHEMICALS		1 Sample(s) between 6/1/2007 to 10/31/2007	
SYNTHETIC ORGANIC CHEMICALS	ALACHLOR (LASSO) (2051) ATRAZINE (2050) SIMAZINE (2037)	Test for each chemical per sample 1 sample between 5/1/2007 and 7/31/2007	

\* A paired sample set refers to one source water and one treated water sample. A source water alkalinity is also required at the same time the TOC sample is taken.

**2007 CHEMICAL MONITORING DISTRIBUTION POINT SCHEDULE**

PWS ID: OH4700411 PWS Name: ELYRIA WATER DEPARTMENT

PWS Type: Community Surface Water Population Served: 68000

DISTRIBUTION ID: DS1 **Sample Monitoring Point: DS000**

Effective Date: 1/1/07

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Date
TOTAL CHLORINE (1000)	Sample in the distribution system *	
TOTAL HALOACETIC ACIDS (HAA5) (2456) TOTAL TRIHALOMETHANES (TTHM) (2950)	1 Sample(s) quarterly Jan-Mar, Apr-Jun, Jul-Sep, Oct-Dec	
COPPER (1022) LEAD (1030)	Not Required	

**Disinfectants and Disinfection Byproducts Sampling Information**

TTHM and HAA5 sample(s) should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect TTHM and HAA5 samples from other locations in your distribution system, use RD000 as the sample monitoring point. Any questions concerning this schedule or the Disinfectants and Disinfection Byproducts Rule can be directed to Sarah Byerly of the Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

Multiple wells drawing water from a single aquifer may be considered one treatment plant for determining the number of TTHM and HAA5 samples required, with approval from Ohio EPA.

\* Total chlorine samples are collected in the distribution system at the same time and place as total coliforms are sampled.

\*\* One sample for Chlorite at each of the following locations: near the first customer, at a location representative of the average residence time, and at a location reflecting maximum residence time of the water in the distribution system.

**Asbestos Sampling Information**

Collect one sample at a tap served by asbestos-cement pipe. The sample monitoring point (smp) code is DS000. Due to limited Laboratory capacity and a 48 hour filtering requirement, contact your lab early in the monitoring period to schedule a sampling date.

**2007 CHEMICAL MONITORING DISTRIBUTION POINT SCHEDULE**

PWS ID: OH4700803 PWS Name: NORTH RIDGEVILLE CITY PWS  
 PWS Type: Community Purchased Surface Water Population Served: 25200  
 DISTRIBUTION ID: DS1 **Sample Monitoring Point: DS000**

Effective Date: 1/1/07

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Date
TOTAL CHLORINE (1000)	Sample in the distribution system *	
ASBESTOS (1094)	Not Required	
TOTAL HALOACETIC ACIDS (HAA5) (2456) TOTAL TRIHALOMETHANES (TTHM) (2950)	1 Sample(s) quarterly Jan-Mar, Apr-Jun, Jul-Sep, Oct-Dec	
COPPER (1022) LEAD (1030)	Not Required	

**Disinfectants and Disinfection Byproducts Sampling Information**

TTHM and HAA5 sample(s) should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect TTHM and HAA5 samples from other locations in your distribution system, use RD000 as the sample monitoring point. Any questions concerning this schedule or the Disinfectants and Disinfection Byproducts Rule can be directed to Sarah Byerly of the Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

Multiple wells drawing water from a single aquifer may be considered one treatment plant for determining the number of TTHM and HAA5 samples required, with approval from Ohio EPA.

\* Total chlorine samples are collected in the distribution system at the same time and place as total coliforms are sampled.

\*\* One sample for Chlorite at each of the following locations: near the first customer, at a location representative of the average residence time, and at a location reflecting maximum residence time of the water in the distribution system.

**Asbestos Sampling Information**

Collect one sample at a tap served by asbestos-cement pipe. The sample monitoring point (smp) code is DS000. Due to limited Laboratory capacity and a 48 hour filtering requirement, contact your lab early in the monitoring period to schedule a sampling date.

### 2007 CHEMICAL MONITORING ENTRY POINT SCHEDULE

PWS ID: OH4700911      PWS NAME: OBERLIN WATER DEPARTMENT  
PWS TYPE: Community    SOURCE: Surface Water    Sample Monitoring Point: EP001  
STU ID: 4755822    STU NAME: OBERLIN WATER DEPARTMENT

Effective Date: 01/01/07

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Chemical Name (Code)	Monitoring Requirements	Sample Date
Consumer Confidence Report (CCR)		CCR is due July 1, 2007	
INORGANICS	ANTIMONY (1074) ARSENIC (1005) BARIUM (1010) BERYLLIUM (1075) CADMIUM (1015) CHROMIUM (1020) CYANIDE (1024) FLUORIDE (1025) MERCURY (1035) NICKEL (1036) SELENIUM (1045) THALLIUM (1085)	1 Sample(s) between 6/1/2007 to 10/31/2007	
NITRATE	NITRATE (AS N) (1040)	1 Sample(s) Monthly	
NITRITE	NITRITE (AS N) (1041)	Not Required	
RADIOLOGICALS	GROSS ALPHA (4002) RADIUM 228 (4010)	Not Required	
TOTAL ORGANIC CARBON (TOC)	TOC (2920)	1 Paired Sample Set Monthly *	
VOLATILE ORGANIC CHEMICALS		1 Sample(s) between 6/1/2007 to 10/31/2007	
SYNTHETIC ORGANIC CHEMICALS	ALACHLOR (LASSO) (2051) ATRAZINE (2050) SIMAZINE (2037)	Test for each chemical per sample 1 sample between 5/1/2007 and 7/31/2007	

\* A paired sample set refers to one source water and one treated water sample. A source water alkalinity is also required at the same time the TOC sample is taken.

## 2007 CHEMICAL MONITORING DISTRIBUTION POINT SCHEDULE

PWS ID: OH4700911 PWS Name: OBERLIN WATER DEPARTMENT

PWS Type: Community Surface Water Population Served: 8600

DISTRIBUTION ID: DS1 **Sample Monitoring Point: DS000**

Effective Date: 1/1/07

### THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Date
TOTAL CHLORINE (1000)	Sample in the distribution system *	
ASBESTOS (1094)	Not Required	
TOTAL HALOACETIC ACIDS (HAA5) (2456) TOTAL TRIHALOMETHANES (TTHM) (2950)	1 Sample(s) quarterly Jan-Mar, Apr-Jun, Jul-Sep, Oct-Dec	
COPPER (1022) LEAD (1030)	Not Required	

### Disinfectants and Disinfection Byproducts Sampling Information

TTHM and HAA5 sample(s) should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect TTHM and HAA5 samples from other locations in your distribution system, use RD000 as the sample monitoring point. Any questions concerning this schedule or the Disinfectants and Disinfection Byproducts Rule can be directed to Sarah Byerly of the Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

Multiple wells drawing water from a single aquifer may be considered one treatment plant for determining the number of TTHM and HAA5 samples required, with approval from Ohio EPA.

\* Total chlorine samples are collected in the distribution system at the same time and place as total coliforms are sampled.

\*\* One sample for Chlorite at each of the following locations: near the first customer, at a location representative of the average residence time, and at a location reflecting maximum residence time of the water in the distribution system.

### Asbestos Sampling Information

Collect one sample at a tap served by asbestos-cement pipe. The sample monitoring point (smp) code is DS000. Due to limited Laboratory capacity and a 48 hour filtering requirement, contact your lab early in the monitoring period to schedule a sampling date.

**2007 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

PWS ID: OH4701511    PWS NAME: WELLINGTON VILLAGE PWS  
PWS TYPE: Community    SOURCE: Surface Water    Sample Monitoring Point: EP001  
STU ID: 4755826    STU NAME: WELLINGTON WTP  
Effective Date: 01/01/07

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Chemical Name (Code)	Monitoring Requirements	Sample Date
Consumer Confidence Report (CCR)		CCR is due July 1, 2007	
INORGANICS	ANTIMONY (1074) ARSENIC (1005) BARIUM (1010) BERYLLIUM (1075) CADMIUM (1015) CHROMIUM (1020) CYANIDE (1024) FLUORIDE (1025) MERCURY (1035) NICKEL (1036) SELENIUM (1045) THALLIUM (1085)	1 Sample(s) between 6/1/2007 to 10/31/2007	
NITRATE	NITRATE (AS N) (1040)	1 Sample(s) Monthly	
NITRITE	NITRITE (AS N) (1041)	Not Required	
RADIOLOGICALS	GROSS ALPHA (4002) RADIUM 228 (4010)	Not Required	
TOTAL ORGANIC CARBON (TOC)	TOC (2920)	1 Paired Sample Set Monthly *	
VOLATILE ORGANIC CHEMICALS		1 Sample(s) between 6/1/2007 to 10/31/2007	
SYNTHETIC ORGANIC CHEMICALS	ALACHLOR (LASSO) (2051) ATRAZINE (2050) SIMAZINE (2037)	Test for each chemical per sample 1 sample between 5/1/2007 and 7/31/2007	

\* A paired sample set refers to one source water and one treated water sample. A source water alkalinity is also required at the same time the TOC sample is taken.

**2007 CHEMICAL MONITORING DISTRIBUTION POINT SCHEDULE**

PWS ID: OH4701511 PWS Name: WELLINGTON VILLAGE PWS

PWS Type: Community Surface Water Population Served: 4900

DISTRIBUTION ID: DS1 **Sample Monitoring Point: DS000**

Effective Date: 1/1/07

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Date
TOTAL CHLORINE (1000)	Sample in the distribution system *	
ASBESTOS (1094)	Not Required	
TOTAL HALOACETIC ACIDS (HAA5) (2456) TOTAL TRIHALOMETHANES (TTHM) (2950)	1 Sample(s) quarterly Jan-Mar, Apr-Jun, Jul-Sep, Oct-Dec	
COPPER (1022) LEAD (1030)	Not Required	

**Disinfectants and Disinfection Byproducts Sampling Information**

TTHM and HAA5 sample(s) should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect TTHM and HAA5 samples from other locations in your distribution system, use RD000 as the sample monitoring point. Any questions concerning this schedule or the Disinfectants and Disinfection Byproducts Rule can be directed to Sarah Byerly of the Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

Multiple wells drawing water from a single aquifer may be considered one treatment plant for determining the number of TTHM and HAA5 samples required, with approval from Ohio EPA.

\* Total chlorine samples are collected in the distribution system at the same time and place as total coliforms are sampled.

\*\* One sample for Chlorite at each of the following locations: near the first customer, at a location representative of the average residence time, and at a location reflecting maximum residence time of the water in the distribution system.

**Asbestos Sampling Information**

Collect one sample at a tap served by asbestos-cement pipe. The sample monitoring point (smp) code is DS000. Due to limited Laboratory capacity and a 48 hour filtering requirement, contact your lab early in the monitoring period to schedule a sampling date.

---

---

**2007 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

PWS ID: OH4737312 PWS NAME: AUTORAMA TWIN THEATER

STU ID: 4755839 STU NAME: AUTORAMA TWIN THEATER

PWS TYPE: Transient Noncommunity Ground Water Sample Monitoring Point: EP001

Effective Date: 1/1/07

---

---

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact Northeast District Office - DDAGW at 330-963-1200 to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

**Chemicals (Code)**

**Monitoring Requirements**

---

---

NITRATE (1040)	1 Sample(s) between 6/1/2007 to 10/31/2007 Sample Date: _____
NITRITE (1041)	Not Required

**2007 CHEMICAL MONITORING DISTRIBUTION POINT SCHEDULE**

PWS ID: OH4700003 PWS Name: AMHERST CITY PWS  
 PWS Type: Community Purchased Surface Water Population Served: 10500  
 DISTRIBUTION ID: DS1 **Sample Monitoring Point: DS000**  
 Effective Date: 1/1/07

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Date
TOTAL CHLORINE (1000)	Sample in the distribution system *	
TOTAL HALOACETIC ACIDS (HAA5) (2456) TOTAL TRIHALOMETHANES (TTHM) (2950)	2 Sample(s) quarterly Jan-Mar, Apr-Jun, Jul-Sep, Oct-Dec	
COPPER (1022) LEAD (1030)	Not Required	

**Disinfectants and Disinfection Byproducts Sampling Information**

TTHM and HAA5 sample(s) should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect TTHM and HAA5 samples from other locations in your distribution system, use RD000 as the sample monitoring point. Any questions concerning this schedule or the Disinfectants and Disinfection Byproducts Rule can be directed to Sarah Byerly of the Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

Multiple wells drawing water from a single aquifer may be considered one treatment plant for determining the number of TTHM and HAA5 samples required, with approval from Ohio EPA.

\* Total chlorine samples are collected in the distribution system at the same time and place as total coliforms are sampled.

\*\* One sample for Chlorite at each of the following locations: near the first customer, at a location representative of the average residence time, and at a location reflecting maximum residence time of the water in the distribution system.

**Asbestos Sampling Information**

Collect one sample at a tap served by asbestos-cement pipe. The sample monitoring point (smp) code is DS000. Due to limited Laboratory capacity and a 48 hour filtering requirement, contact your lab early in the monitoring period to schedule a sampling date.

**2007 CHEMICAL MONITORING DISTRIBUTION POINT SCHEDULE**

PWS ID: OH4701912 PWS Name: PHEASANT RUN ASSOCIATION PWS  
PWS Type: Community Purchased Surface Water Population Served: 2000  
DISTRIBUTION ID: DS1 **Sample Monitoring Point: DS000**

Effective Date: 1/1/07

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Date
TOTAL CHLORINE (1000)	Sample in the distribution system *	
TOTAL HALOACETIC ACIDS (HAA5) (2456) TOTAL TRIHALOMETHANES (TTHM) (2950)	1 Sample(s) quarterly Jan-Mar, Apr-Jun, Jul-Sep, Oct-Dec	
COPPER (1022) LEAD (1030)	10 Sample(s) between 6/1/2007 to 9/30/2007	

**Disinfectants and Disinfection Byproducts Sampling Information**

TTHM and HAA5 sample(s) should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect TTHM and HAA5 samples from other locations in your distribution system, use RD000 as the sample monitoring point. Any questions concerning this schedule or the Disinfectants and Disinfection Byproducts Rule can be directed to Sarah Byerly of the Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

Multiple wells drawing water from a single aquifer may be considered one treatment plant for determining the number of TTHM and HAA5 samples required, with approval from Ohio EPA.

\* Total chlorine samples are collected in the distribution system at the same time and place as total coliforms are sampled.

\*\* One sample for Chlorite at each of the following locations: near the first customer, at a location representative of the average residence time, and at a location reflecting maximum residence time of the water in the distribution system.

**Asbestos Sampling Information**

Collect one sample at a tap served by asbestos-cement pipe. The sample monitoring point (smp) code is DS000. Due to limited Laboratory capacity and a 48 hour filtering requirement, contact your lab early in the monitoring period to schedule a sampling date.

**2007 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

PWS ID: OH4700311    PWS NAME: AVON LAKE CITY PWS  
PWS TYPE: Community    SOURCE: Surface Water    Sample Monitoring Point: EP001  
STU ID: 4755816    STU NAME: AVON LAKE UTILITIES DEPT WTP

Effective Date: 01/01/07

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Chemical Name (Code)	Monitoring Requirements	Sample Date
Consumer Confidence Report (CCR)		CCR is due July 1, 2007	
INORGANICS	ANTIMONY (1074) ARSENIC (1005) BARIUM (1010) BERYLLIUM (1075) CADMIUM (1015) CHROMIUM (1020) CYANIDE (1024) FLUORIDE (1025) MERCURY (1035) NICKEL (1036) SELENIUM (1045) THALLIUM (1085)	1 Sample(s) between 6/1/2007 to 10/31/2007	
NITRATE	NITRATE (AS N) (1040)	1 Sample(s) Monthly	
NITRITE	NITRITE (AS N) (1041)	Not Required	
RADIOLOGICALS	GROSS ALPHA (4002) RADIUM 228 (4010)	Not Required	
TOTAL ORGANIC CARBON (TOC)	TOC (2920)	1 Paired Sample Set Monthly *	
VOLATILE ORGANIC CHEMICALS		1 Sample(s) between 6/1/2007 to 10/31/2007	
SYNTHETIC ORGANIC CHEMICALS	ALACHLOR (LASSO) (2051) ATRAZINE (2050) SIMAZINE (2037)	Test for each chemical per sample 1 sample between 5/1/2007 and 7/31/2007	

\* A paired sample set refers to one source water and one treated water sample. A source water alkalinity is also required at the same time the TOC sample is taken.

**2007 CHEMICAL MONITORING DISTRIBUTION POINT SCHEDULE**

PWS ID: OH4700311 PWS Name: AVON LAKE CITY PWS  
PWS Type: Community Surface Water Population Served: 21333  
DISTRIBUTION ID: DS1 **Sample Monitoring Point: DS000**  
Effective Date: 1/1/07

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Date
TOTAL CHLORINE (1000)	Sample in the distribution system *	
ASBESTOS (1094)	Not Required	
TOTAL HALOACETIC ACIDS (HAA5) (2456) TOTAL TRIHALOMETHANES (TTHM) (2950)	1 Sample(s) quarterly Jan-Mar, Apr-Jun, Jul-Sep, Oct-Dec	
COPPER (1022) LEAD (1030)	30 Sample(s) between 6/1/2007 to 9/30/2007	

**Disinfectants and Disinfection Byproducts Sampling Information**

TTHM and HAA5 sample(s) should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect TTHM and HAA5 samples from other locations in your distribution system, use RD000 as the sample monitoring point. Any questions concerning this schedule or the Disinfectants and Disinfection Byproducts Rule can be directed to Sarah Byerly of the Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

Multiple wells drawing water from a single aquifer may be considered one treatment plant for determining the number of TTHM and HAA5 samples required, with approval from Ohio EPA.

\* Total chlorine samples are collected in the distribution system at the same time and place as total coliforms are sampled.

\*\* One sample for Chlorite at each of the following locations: near the first customer, at a location representative of the average residence time, and at a location reflecting maximum residence time of the water in the distribution system.

**Asbestos Sampling Information**

Collect one sample at a tap served by asbestos-cement pipe. The sample monitoring point (smp) code is DS000. Due to limited Laboratory capacity and a 48 hour filtering requirement, contact your lab early in the monitoring period to schedule a sampling date.

---

---

**2007 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

PWS ID: OH4736912 PWS NAME: PANTHER TRAILS CAMPGROUND

STU ID: 4755837 STU NAME: PANTHER TRAILS CAMPGROUND

PWS TYPE: Transient Noncommunity Ground Water Sample Monitoring Point: EP001

Effective Date: 1/1/07

---

---

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact Northeast District Office - DDAGW at 330-963-1200 to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

**Chemicals (Code)**

**Monitoring Requirements**

---

---

NITRATE (1040)	1 Sample(s) between 6/1/2007 to 10/31/2007 Sample Date: _____
NITRITE (1041)	Not Required

---

---

**2007 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

PWS ID: OH4737512 PWS NAME: MELODY GROVE PWS

STU ID: 4761458 STU NAME: MELODY GROVE

PWS TYPE: Transient Noncommunity Ground Water Sample Monitoring Point: EP001

Effective Date: 1/1/07

---

---

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact Northeast District Office - DDAGW at 330-963-1200 to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

**Chemicals (Code)**

**Monitoring Requirements**

---

---

NITRATE (1040)

1 Sample(s) between 6/1/2007 to 10/31/2007

Sample Date: \_\_\_\_\_

NITRITE (1041)

Not Required

**2007 CHEMICAL MONITORING DISTRIBUTION POINT SCHEDULE**

PWS ID: OH4700203 PWS Name: AVON CITY PWS  
PWS Type: Community Purchased Surface Water Population Served: 12000  
DISTRIBUTION ID: DS1 **Sample Monitoring Point: DS000**

Effective Date: 1/1/07

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Date
TOTAL CHLORINE (1000)	Sample in the distribution system *	
ASBESTOS (1094)	Not Required	
TOTAL HALOACETIC ACIDS (HAA5) (2456) TOTAL TRIHALOMETHANES (TTHM) (2950)	1 Sample(s) quarterly Jan-Mar, Apr-Jun, Jul-Sep, Oct-Dec	
COPPER (1022) LEAD (1030)	Not Required	

**Disinfectants and Disinfection Byproducts Sampling Information**

TTHM and HAA5 sample(s) should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect TTHM and HAA5 samples from other locations in your distribution system, use RD000 as the sample monitoring point. Any questions concerning this schedule or the Disinfectants and Disinfection Byproducts Rule can be directed to Sarah Byerly of the Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

Multiple wells drawing water from a single aquifer may be considered one treatment plant for determining the number of TTHM and HAA5 samples required, with approval from Ohio EPA.

\* Total chlorine samples are collected in the distribution system at the same time and place as total coliforms are sampled.

\*\* One sample for Chlorite at each of the following locations: near the first customer, at a location representative of the average residence time, and at a location reflecting maximum residence time of the water in the distribution system.

**Asbestos Sampling Information**

Collect one sample at a tap served by asbestos-cement pipe. The sample monitoring point (smp) code is DS000. Due to limited Laboratory capacity and a 48 hour filtering requirement, contact your lab early in the monitoring period to schedule a sampling date.

**2007 CHEMICAL MONITORING DISTRIBUTION POINT SCHEDULE**

PWS ID: OH4700603 PWS Name: LAGRANGE VILLAGE PWS

PWS Type: Community Purchased Surface Water Population Served: 1900

DISTRIBUTION ID: DS1 **Sample Monitoring Point: DS000**

Effective Date: 1/1/07

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Date
TOTAL CHLORINE (1000)	Sample in the distribution system *	
TOTAL HALOACETIC ACIDS (HAA5) (2456) TOTAL TRIHALOMETHANES (TTHM) (2950)	1 Sample(s) quarterly Jan-Mar, Apr-Jun, Jul-Sep, Oct-Dec	
COPPER (1022) LEAD (1030)	Not Required	

**Disinfectants and Disinfection Byproducts Sampling Information**

TTHM and HAA5 sample(s) should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect TTHM and HAA5 samples from other locations in your distribution system, use RD000 as the sample monitoring point. Any questions concerning this schedule or the Disinfectants and Disinfection Byproducts Rule can be directed to Sarah Byerly of the Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

Multiple wells drawing water from a single aquifer may be considered one treatment plant for determining the number of TTHM and HAA5 samples required, with approval from Ohio EPA.

\* Total chlorine samples are collected in the distribution system at the same time and place as total coliforms are sampled.

\*\* One sample for Chlorite at each of the following locations: near the first customer, at a location representative of the average residence time, and at a location reflecting maximum residence time of the water in the distribution system.

**Asbestos Sampling Information**

Collect one sample at a tap served by asbestos-cement pipe. The sample monitoring point (smp) code is DS000. Due to limited Laboratory capacity and a 48 hour filtering requirement, contact your lab early in the monitoring period to schedule a sampling date.

**2007 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

PWS ID: OH4700711    PWS NAME: LORAIN CITY PWS  
PWS TYPE: Community    SOURCE: Surface Water    Sample Monitoring Point: EP001  
STU ID: 4755820    STU NAME: LORAIN WTP  
Effective Date: 01/01/07

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Chemical Name (Code)	Monitoring Requirements	Sample Date
Consumer Confidence Report (CCR)		CCR is due July 1, 2007	
INORGANICS	ANTIMONY (1074) ARSENIC (1005) BARIUM (1010) BERYLLIUM (1075) CADMIUM (1015) CHROMIUM (1020) CYANIDE (1024) FLUORIDE (1025) MERCURY (1035) NICKEL (1036) SELENIUM (1045) THALLIUM (1085)	1 Sample(s) between 6/1/2007 to 10/31/2007	
NITRATE	NITRATE (AS N) (1040)	1 Sample(s) Monthly	
NITRITE	NITRITE (AS N) (1041)	Not Required	
RADIOLOGICALS	GROSS ALPHA (4002) RADIUM 228 (4010)	Not Required	
TOTAL ORGANIC CARBON (TOC)	TOC (2920)	1 Paired Sample Set Monthly *	
VOLATILE ORGANIC CHEMICALS		1 Sample(s) between 6/1/2007 to 10/31/2007	
SYNTHETIC ORGANIC CHEMICALS	ALACHLOR (LASSO) (2051) ATRAZINE (2050) SIMAZINE (2037)	Test for each chemical per sample 1 sample between 5/1/2007 and 7/31/2007	

\* A paired sample set refers to one source water and one treated water sample. A source water alkalinity is also required at the same time the TOC sample is taken.

**2007 CHEMICAL MONITORING DISTRIBUTION POINT SCHEDULE**

PWS ID: OH4700711 PWS Name: LORAIN CITY PWS  
PWS Type: Community Surface Water Population Served: 69800  
DISTRIBUTION ID: DS1 **Sample Monitoring Point: DS000**

Effective Date: 1/1/07

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Date
TOTAL CHLORINE (1000)	Sample in the distribution system *	
TOTAL HALOACETIC ACIDS (HAA5) (2456) TOTAL TRIHALOMETHANES (TTHM) (2950)	1 Sample(s) quarterly Jan-Mar, Apr-Jun, Jul-Sep, Oct-Dec	
COPPER (1022) LEAD (1030)	Not Required	

**Disinfectants and Disinfection Byproducts Sampling Information**

TTHM and HAA5 sample(s) should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect TTHM and HAA5 samples from other locations in your distribution system, use RD000 as the sample monitoring point. Any questions concerning this schedule or the Disinfectants and Disinfection Byproducts Rule can be directed to Sarah Byerly of the Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

Multiple wells drawing water from a single aquifer may be considered one treatment plant for determining the number of TTHM and HAA5 samples required, with approval from Ohio EPA.

\* Total chlorine samples are collected in the distribution system at the same time and place as total coliforms are sampled.

\*\* One sample for Chlorite at each of the following locations: near the first customer, at a location representative of the average residence time, and at a location reflecting maximum residence time of the water in the distribution system.

**Asbestos Sampling Information**

Collect one sample at a tap served by asbestos-cement pipe. The sample monitoring point (smp) code is DS000. Due to limited Laboratory capacity and a 48 hour filtering requirement, contact your lab early in the monitoring period to schedule a sampling date.

**2007 CHEMICAL MONITORING DISTRIBUTION POINT SCHEDULE**

PWS ID: OH4701103 PWS Name: SHEFFIELD LAKE CITY PWS

PWS Type: Community Purchased Surface Water Population Served: 9800

DISTRIBUTION ID: DS1 **Sample Monitoring Point: DS000**

Effective Date: 1/1/07

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Date
-----------	-------------------------	-------------

TOTAL CHLORINE (1000)	Sample in the distribution system *	
-----------------------	-------------------------------------	--

ASBESTOS (1094)	Not Required	
-----------------	--------------	--

TOTAL HALOACETIC ACIDS (HAA5) (2456) TOTAL TRIHALOMETHANES (TTHM) (2950)	1 Sample(s) between 7/1/2007 to 9/30/2007	
---	---	--

COPPER (1022) LEAD (1030)	20 Sample(s) between 6/1/2007 to 9/30/2007	
------------------------------	--	--

--	--	--

**Disinfectants and Disinfection Byproducts Sampling Information**

TTHM and HAA5 sample(s) should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect TTHM and HAA5 samples from other locations in your distribution system, use RD000 as the sample monitoring point. Any questions concerning this schedule or the Disinfectants and Disinfection Byproducts Rule can be directed to Sarah Byerly of the Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

Multiple wells drawing water from a single aquifer may be considered one treatment plant for determining the number of TTHM and HAA5 samples required, with approval from Ohio EPA.

\* Total chlorine samples are collected in the distribution system at the same time and place as total coliforms are sampled.

\*\* One sample for Chlorite at each of the following locations: near the first customer, at a location representative of the average residence time, and at a location reflecting maximum residence time of the water in the distribution system.

**Asbestos Sampling Information**

Collect one sample at a tap served by asbestos-cement pipe. The sample monitoring point (smp) code is DS000. Due to limited Laboratory capacity and a 48 hour filtering requirement, contact your lab early in the monitoring period to schedule a sampling date.

**2007 CHEMICAL MONITORING DISTRIBUTION POINT SCHEDULE**

PWS ID: OH4701803 PWS Name: RURAL LORAIN CO. WATER A  
 PWS Type: Community Purchased Surface Water Population Served: 62305  
 DISTRIBUTION ID: DS1 **Sample Monitoring Point: DS000**

Effective Date: 2/14/07

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Monitoring Requirements</b>	<b>Sample Date</b>
------------------	--------------------------------	--------------------

TOTAL CHLORINE (1000)	Sample in the distribution system *	
-----------------------	-------------------------------------	--

ASBESTOS (1094)	Not Required	
-----------------	--------------	--

TOTAL HALOACETIC ACIDS (HAA5) (2456) TOTAL TRIHALOMETHANES (TTHM) (2950)	8 Sample(s) quarterly Jan-Mar, Apr-Jun, Jul-Sep, Oct-Dec	
---	--	--

COPPER (1022) LEAD (1030)	Not Required	
------------------------------	--------------	--

--	--	--

**Disinfectants and Disinfection Byproducts Sampling Information**

TTHM and HAA5 sample(s) should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect TTHM and HAA5 samples from other locations in your distribution system, use RD000 as the sample monitoring point. Any questions concerning this schedule or the Disinfectants and Disinfection Byproducts Rule can be directed to Sarah Byerly of the Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

Multiple wells drawing water from a single aquifer may be considered one treatment plant for determining the number of TTHM and HAA5 samples required, with approval from Ohio EPA.

\* Total chlorine samples are collected in the distribution system at the same time and place as total coliforms are sampled.

\*\* One sample for Chlorite at each of the following locations: near the first customer, at a location representative of the average residence time, and at a location reflecting maximum residence time of the water in the distribution system.

**Asbestos Sampling Information**

Collect one sample at a tap served by asbestos-cement pipe. The sample monitoring point (smp) code is DS000. Due to limited Laboratory capacity and a 48 hour filtering requirement, contact your lab early in the monitoring period to schedule a sampling date.

**2007 CHEMICAL MONITORING DISTRIBUTION POINT SCHEDULE**

PWS ID: OH4701203 PWS Name: SHEFFIELD VILLAGE PWS

PWS Type: Community Purchased Surface Water Population Served: 2989

DISTRIBUTION ID: DS1 **Sample Monitoring Point: DS000**

Effective Date: 1/1/07

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

Chemicals	Monitoring Requirements	Sample Date
-----------	-------------------------	-------------

TOTAL CHLORINE (1000)	Sample in the distribution system *	
-----------------------	-------------------------------------	--

ASBESTOS (1094)	Not Required	
-----------------	--------------	--

TOTAL HALOACETIC ACIDS (HAA5) (2456) TOTAL TRIHALOMETHANES (TTHM) (2950)	1 Sample(s) between 7/1/2007 to 9/30/2007	
---	---	--

COPPER (1022) LEAD (1030)	Not Required	
------------------------------	--------------	--

--	--	--

**Disinfectants and Disinfection Byproducts Sampling Information**

TTHM and HAA5 sample(s) should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect TTHM and HAA5 samples from other locations in your distribution system, use RD000 as the sample monitoring point. Any questions concerning this schedule or the Disinfectants and Disinfection Byproducts Rule can be directed to Sarah Byerly of the Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

Multiple wells drawing water from a single aquifer may be considered one treatment plant for determining the number of TTHM and HAA5 samples required, with approval from Ohio EPA.

\* Total chlorine samples are collected in the distribution system at the same time and place as total coliforms are sampled.

\*\* One sample for Chlorite at each of the following locations: near the first customer, at a location representative of the average residence time, and at a location reflecting maximum residence time of the water in the distribution system.

**Asbestos Sampling Information**

Collect one sample at a tap served by asbestos-cement pipe. The sample monitoring point (smp) code is DS000. Due to limited Laboratory capacity and a 48 hour filtering requirement, contact your lab early in the monitoring period to schedule a sampling date.

**2007 CHEMICAL MONITORING DISTRIBUTION POINT SCHEDULE**

PWS ID: OH4701411 PWS Name: SOUTH AMHERST VILLAGE PWS  
 PWS Type: Community Purchased Surface Water Population Served: 1850  
 DISTRIBUTION ID: DS1 **Sample Monitoring Point: DS000**

Effective Date: 1/1/07

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact your district office to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

<b>Chemicals</b>	<b>Monitoring Requirements</b>	<b>Sample Date</b>
------------------	--------------------------------	--------------------

TOTAL CHLORINE (1000)	Sample in the distribution system *	
-----------------------	-------------------------------------	--

TOTAL HALOACETIC ACIDS (HAA5) (2456) TOTAL TRIHALOMETHANES (TTHM) (2950)	1 Sample(s) quarterly Jan-Mar, Apr-Jun, Jul-Sep, Oct-Dec	
---	--	--

COPPER (1022)	Not Required	
---------------	--------------	--

LEAD (1030)		
-------------	--	--

--	--	--

**Disinfectants and Disinfection Byproducts Sampling Information**

TTHM and HAA5 sample(s) should be collected from point(s) in the distribution system where the water age is the oldest. Use MR000 as the sample monitoring point. If your system is also required to collect TTHM and HAA5 samples from other locations in your distribution system, use RD000 as the sample monitoring point. Any questions concerning this schedule or the Disinfectants and Disinfection Byproducts Rule can be directed to Sarah Byerly of the Ohio EPA DDAGW Central Office at (614) 644-2752. Your district office representative is also available to provide assistance.

Multiple wells drawing water from a single aquifer may be considered one treatment plant for determining the number of TTHM and HAA5 samples required, with approval from Ohio EPA.

\* Total chlorine samples are collected in the distribution system at the same time and place as total coliforms are sampled.

\*\* One sample for Chlorite at each of the following locations: near the first customer, at a location representative of the average residence time, and at a location reflecting maximum residence time of the water in the distribution system.

**Asbestos Sampling Information**

Collect one sample at a tap served by asbestos-cement pipe. The sample monitoring point (smp) code is DS000. Due to limited Laboratory capacity and a 48 hour filtering requirement, contact your lab early in the monitoring period to schedule a sampling date.

---

---

**2007 CHEMICAL MONITORING ENTRY POINT SCHEDULE**

PWS ID: OH4731012    PWS NAME: CRYSTAL SPRINGS CAMPGROUND, LIMITED PWS

STU ID: 4755829    STU NAME: CRYSTAL SPRINGS CAMPGROUND LTD

PWS TYPE: Transient Noncommunity Ground Water    Sample Monitoring Point: EP001

Effective Date: 1/1/07

---

---

**THIS SCHEDULE DOES NOT INCLUDE ALL MONITORING REQUIREMENTS FOR YOUR SYSTEM.**

Contact Northeast District Office - DDAGW at 330-963-1200 to review additional monitoring for coliform, monthly operating parameters, and/or other monitoring requirements not included on this schedule. For water emergencies that occur after hours, please call 800-282-9378

**Chemicals (Code)**

**Monitoring Requirements**

---

---

NITRATE (1040)	1 Sample(s) between 6/1/2007 to 10/31/2007 Sample Date: _____
NITRITE (1041)	Not Required